

Step 1. Feed lanyard through the core of the tape roll.



Step 2. Feed the loop end through a D-Ring or Molle loop on your pack where you want to hang the tape.



Step 3. Slip the end of the tape roll into the loop end and feed it all the way over it.



Step 4 Pull all the way through and you're done! Just reverse the process to remove or refill.

